

Errata

Title & Document Type: 5501A Laser Transducer Operating and Service Manual

Manual Part Number: 05501-90025

Revision Date: May 1981

About this Manual

We've added this manual to the Agilent website in an effort to help you support your product. This manual provides the best information we could find. It may be incomplete or contain dated information, and the scan quality may not be ideal. If we find a better copy in the future, we will add it to the Agilent website.

HP References in this Manual

This manual may contain references to HP or Hewlett-Packard. Please note that Hewlett-Packard's former test and measurement, life sciences, and chemical analysis businesses are now part of Agilent Technologies. The HP XXXX referred to in this document is now the Agilent XXXX. For example, model number HP8648A is now model number Agilent 8648A. We have made no changes to this manual copy.

Support for Your Product

Agilent no longer sells or supports this product. You will find any other available product information on the Agilent Test & Measurement website:

www.agilent.com

Search for the model number of this product, and the resulting product page will guide you to any available information. Our service centers may be able to perform calibration if no repair parts are needed, but no other support from Agilent is available.



Agilent Technologies

OPERATING AND SERVICE MANUAL

5501A

LASER TRANSDUCER (LASER HEAD)

SERIAL PREFIX: 2020A

This manual applies directly to Hewlett-Packard Model 5501A Laser Transducers having serial prefix 2020A.

SERIAL PREFIXES NOT LISTED

For serial prefixes above 2020A, a Manual Change sheet is included with this manual. For lower serial prefixes, refer to Section VI of this manual.

Copyright HEWLETT-PACKARD COMPANY 1075
5305 STEVENS CREEK BLVD., SANTA CLARA, CALIF. 95050

Manual Part No. 05501-90025
Microfiche No. 05501-90026

Printed: MAY 1981



CERTIFICATION

Hewlett-Packard Company certifies that this product met its published specifications at the time of shipment from the factory. Hewlett-Packard further certifies that its calibration measurements are traceable to the United States National Bureau of Standards, to the extent allowed by the Bureau's calibration facility, and to the calibration facilities of other International Standards Organization members.

WARRANTY

This Hewlett-Packard Instrument product is warranted against defects in materials and workmanship for a period of 90 days from date of shipment. During the warranty period, HP will, at its option, either repair or replace products which prove to be defective.

Warranty service of this product will be performed at Buyer's facility at no charge within HP service travel areas. Outside HP service travel areas, warranty service will be performed at Buyer's facility only upon HP's prior agreement and Buyer shall pay HP's round trip travel expenses. In all other cases, products must be returned to a service facility designated by HP.

For products returned to HP for warranty service, Buyer shall prepay shipping charges to HP and HP shall pay shipping charges to return the product to Buyer. However, Buyer shall pay all shipping charges, duties, and taxes for products returned to HP from another country.

HP warrants that its software and firmware designated by HP for use with an instrument will execute its programming instructions when properly installed on that instrument. HP does not warrant that the operation of the instrument, or software, or firmware will be uninterrupted or error free.

LIMITATION OF WARRANTY

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by Buyer, Buyer-supplied software or interfacing, unauthorized modification or misuse, operation outside of the environmental specifications for the product, or improper site preparation or maintenance.

NO OTHER WARRANTY IS EXPRESSED OR IMPLIED. HP SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

EXCLUSIVE REMEDIES

THE REMEDIES PROVIDED HEREIN ARE BUYER'S SOLE AND EXCLUSIVE REMEDIES. HP SHALL NOT BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER BASED ON CONTRACT, TORT, OR ANY OTHER LEGAL THEORY.

ASSISTANCE

Product maintenance agreements and other customer assistance agreements are available for Hewlett-Packard products.

For any assistance, contact your nearest Hewlett-Packard Sales and Service Office. Addresses are provided at the back of this manual.

SAFETY PRECAUTIONS


This is a Safety Class I system. This system has been designed and tested according to IEC Publication 348, "Safety Requirements for Electronic Measuring Apparatus". This product is also a Class II Laser Product conforming to Federal Bureau of Radiological Health Regulations 21 CFR 1040.10.

CAUTION



LASER RADIATION
DO NOT STARE INTO BEAM

MAXIMUM OUTPUT: 1 mW
PULSE SPEC: continuous wave
LASER MEDIUM: helium neon
CLASS II LASER PRODUCT



**FEDERAL COMMUNICATIONS COMMISSION
RADIO FREQUENCY INTERFERENCE
STATEMENT**

Warning: This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions manual, may cause interference to radio communications. As temporarily permitted by regulation it has not been tested for compliance with the limits for Class A computing devices pursuant to Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference. Operation of this equipment in a residential area is likely to cause interference in which case the user at his own expense will be required to take whatever measures may be required to correct the interference.

LASER TUBE WARRANTY CLAIM

Shipping Instructions

- Keep possession of the defective tube until receipt of the replacement tube.
- Do not discard the shipping carton or the packing material in which the replacement tube is received.
- Place the defective tube in the molded foam packing material and enclose this in the matching shipping carton.
- Fill out and enclose this warranty claim form, seal the carton securely and ship to:

HEWLETT-PACKARD COMPANY
Corporate Parts Center
333 Logue Avenue
Mountain View, CA 94043

IMPORTANT

**FAILURE TO RETURN DEFECTIVE TUBE IN THE ORIGINAL PACKING MATERIAL
MAY VOID WARRANTY.**

FROM: _____ DATE: _____

COMPANY: _____

ADDRESS: _____

For additional information, contact:

NAME: _____

COMPANY: _____

ADDRESS: _____

1. HP INSTRUMENT a. MODEL: _____

b. SERIAL No. _____

2. TUBE SERIAL No. _____

3. Is defective tube original? YES ☐ NO ☐

4. Date purchased (if available): _____

5. Describe nature and/or symptoms of trouble: _____

6. Describe operating environment (i.e., temperature, humidity, etc.): _____

7. Remarks: _____

TABLE OF CONTENTS

Section	Title	Page
I	GENERAL INFORMATION	1-1
	1-1. Introduction	1-1
	1-3. Equipment Description	1-1
	1-7. Identification	1-1
	1-11. Equipment Supplied	1-1
	1-13. Available Accessories	1-2
	1-15. Specifications	1-3
II	INSTALLATION AND OPERATION	2-1
	2-1. Introduction	2-1
	2-3. Unpacking and Inspection	2-1
	2-5. Packaging for Reshipment	2-1
	2-7. Storage	2-1
	2-9. Installation	2-1
	2-11. Mounting	2-2
	2-13. Power and Signal Connections	2-2
	2-15. Cable Fabrication	2-3
	2-17. Operation	2-3
	2-19. Controls, Connectors, and Indicators	2-3
	2-21. Power Application	2-3
	2-25. Beam Alignment	2-7
III	THEORY OF OPERATION	3-1
	3-1. Introduction	3-1
	3-3. General Description	3-1
	3-15. General Functional Description	3-2
	3-17. Power Distribution	3-2
	3-21. Laser Current Regulation	3-3
	3-25. Automatic PZT Tuning	3-3
	3-34. Control and Diagnostic Monitoring	3-4
IV	MAINTENANCE	4-1
	4-1. Introduction	4-1
	4-3. Performance Check	4-1
	4-6. Instrument Access	4-2
	4-15. Troubleshooting	4-4
	4-17. Adjustment Procedures	4-8
	4-19. Lock Reference Board Adjustments	4-8
	4-26. Laser Tube Current Adjustment	4-10
V	REPLACEABLE PARTS	5-1
	5-1. Introduction	5-1
	5-4. Ordering Information	5-1
VI	MANUAL CHANGES AND OPTIONS	6-1
	6-1. Introduction	6-1
	6-3. Manual Changes	6-1
	6-5. New Instruments	6-1
	6-7. Older Instruments	6-1
	6-9. Options	6-4
VII	CIRCUIT DIAGRAMS	7-1
	7-1. Introduction	7-1

TABLES

Table	Title	Page
1-1	Specifications	1-2
2-1	Laser Head System Signal Chart	2-5
3-1	DC Unbalanced Failures	3-2
4-1	Input Voltage	4-1
4-2	Voltages at Diagnostic Connector	4-1
4-3	Indicator Conditions During Retune	4-2
4-4	Reference Signal	4-2
4-5	Module Adjustment Requirements	4-8
5-1	Replaceable Parts	5-3
5-2	Manufacturers Code List	5-7
6-1	Backdating Changes	6-1
6-2	Power Supply Options	6-2
7-1	Laser Head Module Listing	7-7
7-2	A1 Connector Board Signal List	7-8
7-3	A2 High Voltage Assembly Signal List	7-12
7-4	A5 Lock Reference Board Signal List	7-14
7-5	A6 PZT Power Supply Assembly Signal List	7-16
7-6	A7 Control Board Assembly Signal List	7-10

FIGURES

Figure	Title	Page
1-1	Model 5501A Laser Transducer	1-0
2-1	Mounting Details and Physical Characteristics	2-2
2-2	Typical Transducer System Interconnections	2-3
2-3	Interconnecting Plugs and Cable Details	2-4
2-4	Controls, Connectors, and Indicators	2-7
3-1	Retune Timing Diagram	3-5
4-1	Troubleshooting Flow Chart	4-5
4-2	Laser Current Loop Failure Analysis	4-6
4-3	Automatic Retune Loop Failure Analysis	4-7
4-4	A5 Lock Reference Board Adjustment Locations	4-9
4-5	Laser Beam Blocking Method	4-9
4-6	Laser Current Adjustment Locations	4-11
7-1	Schematic Diagram Notes	7-2
7-2	IC Diagrams	7-3
7-3	Laser Head Assembly Locations	7-6
7-4	Functional Circuit Diagram	7-7
7-5	A1 Connector Board Component Locator	7-10
7-6	A1 Connector Board Schematic Diagram	7-11
7-7	A2 H.V. Power Supply Assembly Schematic Diagram	7-13
7-8	A5 Lock Reference Board Component Locator	7-15
7-9	A5 Lock Reference Board Schematic Diagram	7-15
7-10	A6 PZT Power Supply Assembly Schematic Diagram	7-17
7-11	A7 Control Board Component Locator	7-19
7-12	A7 Control Board Schematic Diagram	7-19

Model 5501A
General Information




Figure 1-1. Model 5501A Laser Transducer

SECTION I GENERAL INFORMATION

1-1. INTRODUCTION

1-2. This section of the manual provides a description of the HP 5501A Laser Transducer, hereafter called the laser head. Information regarding identification of the manual, the laser head, and circuit boards within the unit, general applications information, and complete specifications (Table 1-1), is also included.

1-3. EQUIPMENT DESCRIPTION

1-4. The laser head (Figure 1-1) is a high stability laser source that generates a coherent light beam to a receiver through the system optics. The laser head also generates an electrical reference signal REF which is compared with the received electrical signal MEAS (from a 10700A Receiver) to provide displacement information.

1-5. As an additional feature, the laser head provides visual and electrical diagnostic outputs that indicate its operational status. Remotely activated tuning can be performed via the diagnostic circuits.

1-6. The laser head consists of three printed-circuit boards, two sealed modules, a laser tube, and internal optics mounted in a NEMA type 12 enclosure. These components maintain optimum laser beam operation, as well as provide continuous laser reference and status information.

1-7. IDENTIFICATION

1-8. This manual is identified on the title page by equipment description and nomenclature, manual part number, and publication data. Refer to information presented in the following paragraphs and ensure that this manual applies to equipment being serviced.

1-9. Hewlett-Packard Instruments have a two-section, nine-digit plus one-letter serial number usually attached to the instrument rear panel. The four-digit prefix (first four digits from the left) identifies a group of instruments. The letter indicates the assembly plant location. The five-digit serial number is different for each instrument. If the serial prefix of your instrument differs from that listed on the title page of this manual, there are differences between this manual and your instrument.

1-10. The printed-circuit boards within the instrument are identified by a two-section, 10-digit part number (e.g., 05501-60001) and a four-digit series number (e.g., "SERIES 1404"). The series number identifies the electrical characteristics of the complete printed-circuit assembly. A replacement circuit-board assembly may have a different series number than the assembly originally supplied with the instrument. Therefore, when troubleshooting a circuit-board assembly, ensure that the series number on the schematic diagram matches the series number on the board assembly. If the series number on the assembly is lower than the number on the schematic diagram in Section VII, refer to Section VI of this manual for change information. If the series number on the assembly is higher than the number on the schematic diagram, the change information is provided in a manual change sheet which is available from the nearest Hewlett-Packard Sales and Service Office.

1-11. EQUIPMENT SUPPLIED

1-12. The Laser Head is supplied with the following connectors to allow for fabricating the power and reference cables; 4-pin conductor HP P/N 1251-3447, and 4-pin connector HP P/N 1251-3450. Refer to the 5501A Laser Transducer System Manual Backdating section for fabrication instructions. Also supplied is a Diagnostic connector 18-pin HP P/N 1251-2797. Fabricated cables may be ordered. These are 10770A (3 metres), 10778B (10 metres), or 10778C (20 metres) for the power cable and 10779A, B, or C for the reference cable.

Model 5501A
General Information

1-13. AVAILABLE ACCESSORIES

1-14. Refer to the 5501A Laser Transducer System Operating and Service Manual for available accessories.

1-15. SPECIFICATIONS

1-16. All technical specifications for the laser head are listed in Table 1-1.

Table 1-1. Specifications

LASER:

Helium-Neon Type with Zeeman frequency split beam, zero warm-up time, automatically tuned.

BEAM POWER OUTPUT:

1 milliwatt maximum.

BEAM DIAMETER:

7 mm (0.28 inches)

ELECTRICAL SPECIFICATIONS

UNIT POWER REQUIREMENTS:

+15 volts ± 0.25 Vdc 0.6 amp

-15 volts ± 0.25 Vdc 0.5 amp

NOTE

Internal Laser Head 2 amp fuses permit power distribution to other Laser Transducer units.

SAFETY FEATURES:

1. Front shutter to block Laser Beam.
2. Safety switch that disables high voltage when cover is removed.

OUTPUTS:

Reference signal: Differential squarewave at approximately 1.8 MHz. Levels compatible with all Laser Transducer System output accessories.

Diagnostics: Set of TTL level signals.

PHYSICAL SPECIFICATIONS

ENCLOSURE:

NEMA type 12.

WEIGHT:

3.9 kg (8.5 pounds)

INSTALLATION

AND

OPERATION

SECTION II INSTALLATION AND OPERATION

2-1. INTRODUCTION

2-2. This section of the manual contains unpacking, inspection, storage, and shipping information, in addition to detailed installation and operation instructions.

2-3. UNPACKING AND INSPECTION

2-4. If the shipping carton is damaged, inspect the unit for visible damage (scratches, dents, etc.). If the unit is damaged, notify the carrier and the nearest Hewlett-Packard Sales and Service Office immediately (offices are listed at the back of this manual). Keep the shipping carton and packing material for the carrier's inspection. The HP Sales and Service Office will arrange for repair or replacement of the unit without waiting for a claim against the carrier to be settled.

2-5. PACKAGING FOR RESHIPMENT

2-6. If it becomes necessary to reship the unit, use good commercial packaging. The same containers and materials used for factory packaging can be obtained through the Hewlett-Packard Sales and Service Offices listed at the back of this manual. Contract packaging companies in many cities can also provide dependable custom packaging on short notice. Adhere to the following general instructions when repacking the unit.

- a. If shipping to a Hewlett-Packard Service Office or Center, attach a tag indicating the type of service required, return address, model number and full serial number.
- b. Wrap the unit in heavy paper or plastic.
- c. Use a strong shipping container. A double-wall carton made of 350 pound test material is adequate.
- d. Use enough shock-absorbing material (three to four inch layer) around all sides of the unit to provide a firm cushion and prevent movement inside the container. Protect the front and rear panels with cardboard.
- e. Seal the shipping container securely.
- f. Mark the shipping container FRAGILE to assure careful handling.

2-7. STORAGE

2-8. If the instrument is to be stored for an extended period of time, it should be enclosed in a clean, sealed container.

2-9. INSTALLATION

2-10. The following paragraphs describe mounting procedures, required power and signal interconnections, and fabrication of interconnecting cables.




Figure 2-1. Mounting Details and Physical Characteristics

2-11. Mounting

2-12. Mount the laser head by means of the three slotted mounting tabs that extend outward from the bottom edges of the unit (refer to Figure 2-1 for exact locations and dimensions). The mounting tabs may be secured to the work surface in any fashion that will not transmit stresses to the main enclosure and, consequently, to the laser tube or printed-circuit assemblies. If necessary, the tabs can be removed and the unit can be mounted on a flat surface with 8-32 machine screws; use the same tapped holes that are used to secure the tabs.

CAUTION

Do not clamp the unit at any point other than the mounting tabs.
To do so can damage the unit.

2-13. Power and Signal Connections

2-14. The laser head rear panel contains three multi-pin connectors that are used for power and signal connection of the laser head to the remaining components of a laser transducer system. (Refer to Figure 2-2 for an interconnection diagram of a typical system.) Table 2-1 lists all power and signal lines that are available at the three rear-panel connectors. The laser transducer system manual gives additional system wiring information.




Figure 2-2. Typical Transducer System Interconnections

2-15. Cable Fabrication

2-16. Power and signal interconnecting cables of suitable length must be fabricated using the three plugs included with the laser head. Figure 2-3 illustrates the physical details of the three supplied plugs and gives part numbers for both the plugs and the recommended cables. Refer to Table 2-1 for rear-panel connector pin numbers of all available power and signal lines.

2-17. OPERATION

2-18. The following paragraphs describe the laser head controls, connectors, and indicators, and describe the steps necessary to apply power to the laser head and to verify that the laser beam is aligned through the optical components of the system.

2-19. Controls, Connectors, and Indicators


2-20. Figure 2-4 identifies and describes each of the operating controls, connectors, and indicators. Refer to Table 2-1 for information regarding the specific power and signal lines that are available at each of the connectors.

2-21. Power Application

2-22. The installed laser head unit is activated when +15 Vdc and -15 Vdc are applied to the unit. After connecting the POWER plug, measure the voltage at pins A and B of the diagnostics connector and ensure that the power source is adjusted to conform to the following requirements.

Pin (+)	Pin (-)	Measured Voltage
A	D	+15V $\pm$ 0.25 Vdc
D	B	-15V $\pm$ 0.25 Vdc

Model 5501A
Installation and Operation




PLUG	CABLE	DESCRIPTION
REFERENCE SIGNAL HP Part No. 1251-3447	HP10779A/B/C or equivalent	Dual coax; two #22 power wires. Everything enclosed by a second insulated shield.
POWER HP Part No. 1251-3450	HP10778A/B/C or equivalent	Three #20 wires

Figure 2-3. Interconnecting Plugs and Cable Details

Table 2-1. Laser Head System Signal Chart

Input	Output	Signal Name	Function	Source	Destination
	J1-A	Fused +15V	Accessory +15V Operating Power		Accessory Equipment
	J1-B	Fused +15V RET	Accessory +15V Return		Accessory Equipment
	J1-C J1-D	$\left. \begin{array}{c} \text{REF} \\ \text{REF} \end{array} \right\}$	System Reference Measurement signal, equal to the difference in frequency between the Laser f_1 and f_2 components.		Accessory Equipment
J2-A J2-B		+15V -15V	External +15V power input External -15V power input	Ext. Pwr. Sup. Ext. Pwr. Sup.	
	J2-C	+5V	+5V power test point		Accessory Equipment (test use only)
J2-D		GND	Power Ground	Ext. Pwr. Sup.	
J3-E	J3-A	+15 TEST	+15V sample for diagnostics		Accessory Equipment
	J3-B	-15 TEST	-15V sample for diagnostics		Accessory Equipment
	J3-C	+5 TEST	+5V sample for diagnostics		Accessory Equipment
	J3-D	SYS COM	System Common return		Accessory Equipment
		RETUNE CMD	Active low signal; external input to initiate PZT Tune/Check cycle	Accessory Equipment	
	J3-F	RETUNE FAILURE	Active high diagnostic signal indicating failure of the PZT Tuning/Check cycle		Accessory Equipment
	J3-I	RETUNE STATUS	Active high diagnostic signal indicating PZT Tuning/Check cycle is in process		Accessory Equipment
	J3-K	LASER CURRENT ERROR	Active high diagnostic signal indicating Laser Tube current is not within minimum and maximum limits		Accessory Equipment
	J3-L	ERROR	Active high diagnostic signal indicating any or all of the following conditions: 1. Laser Tube current out of specifications 2. PZT voltage out of specifications 3. Retune/Check cycle in process		Accessory Equipment
	J3-M	L1 MON TEST	Laser current sample for diagnostics		Accessory Equipment
	J3-N	PZT MON TEST	PZT voltage sample for diagnostics		Accessory Equipment
	J3-P	REF OK STATUS	Active low diagnostic signal indicating Laser is properly tuned		Accessory Equipment



1. +15 UNBAL (LED Lamp)
2. -15 UNBAL (LED Lamp)
3. +15 FUSE (LED Lamp)
4. -15 FUSE (LED Lamp)
5. POWER ON (LED Lamp)
6. LASER CURRENT (LED Lamp)
7. RETUNE FAILURE (LED Lamp)
8. RETUNE (LED Lamp)
9. RETUNE (Pushbutton)
10. REFERENCE SIGNAL (Connector, J1)
11. POWER (Connector, J2)
12. DIAGNOSTIC (Connector, J3)

Lights when +15 Vdc power is high by approximately one volt or more; or when the -15 Vdc power input is low (i.e., less negative) by one volt or more.

Lights when -15 Vdc power is high (i.e., more negative) by approximately one volt or more; or when the +15 Vdc power input is low (i.e., less positive) by one volt or more.

Lights when +15 Vdc fuse blows.

Lights when -15 Vdc fuse blows.

Lights when external power has been applied to Laser Head.

Lights to indicate Laser Tube current is not within appropriate operating limits.

Lights to indicate the Laser Tube is not properly tuned or that retune cycle did not retune the laser.

Lights to indicate that retuning is required or that retune cycle is in progress. Light should go out approximately 9 seconds after the RETUNE pushbutton is depressed. If light remains on, a tuning fault is indicated.

Manually activates Retune sequence.

Allows the reference signals (REF and REF) and +15V power to be interconnected to other system components.

Provides connection point for external power supply input.

Allows monitoring of diagnostic signals and application of RETUNE command by external equipment.

Figure 2-4. Controls, Connectors, and Indicators

2-23. If a delay exists between application of the +15 Vdc and -15 Vdc power, it is preferable to apply +15 Vdc after the -15 Vdc. This provides automatic retune of the laser head upon power turn-on. If +15 Vdc is applied first, the retune cycle is initiated by either manually depressing the RETUNE switch (at the rear of the laser head) or applying a logic low RETUNE CMD signal to pin E of the DIAGNOSTIC connector.

2-24. After power is applied, the POWER ON and RETUNE lamps at the rear of the laser head will remain on. After 9 seconds the RETUNE lamp goes out and only the POWER ON lamp remains lit.

2-25. Beam Alignment

2-26. Rotate the turret at the front of the laser head so that the beam exits through the large aperture. DO NOT STARE DIRECTLY INTO THE BEAM APERTURE. Presence of the red laser beam can be verified by placing a piece of paper in the beam path and observing the beam reflection on the paper. The components of the laser transducer system must now be aligned so that the laser beam strikes the photodetector of the receiver (HP Model 10780A). Refer to the documentation supplied with the receiver and to the Laser Transducer System Manual for further alignment information.

THEORY

SECTION III

THEORY OF OPERATION

3-1. INTRODUCTION

3-2. This section provides the theory of operation for the laser head. The first part presents general laser theory as it applies to the laser head. Subsequent paragraphs described detailed laser head operation; functional analysis of the laser head is included.

3-3. GENERAL DESCRIPTION

3-4. The laser head transmits a coherent light beam (all light waves are in phase) that is used by the laser transducer system to generate displacement measurement signals. In addition to this beam, the laser head generates an electrical reference (REF) signal, and accepts and produces interface and diagnostic signals for accessory equipment. The laser head accepts +15 Vdc and -15 Vdc operating power from an external source and distributes fused +15 Vdc and -15 Vdc to other units of the transducer system.

3-5. The laser head basically consists of a laser tube assembly, regulator circuits that ensure optimum laser operation, and diagnostic circuits.

3-6. The laser tube contains a Helium-Neon gas that is excited when high voltage is supplied. A laser current control circuit maintains the appropriate laser tube current by monitoring cathode current and adjusting the high voltage accordingly.

3-7. The laser tube consists of the anode, cathode, mirrors, a spring, and a piezoelectric transducer. These elements are enclosed in the Helium-Neon environment. As a result of the excitation, light energy in the form of photons are spontaneously emitted by the excited Neon atoms. These photons, traveling approximately at the speed of light, are reflected by the mirrors and collide with Neon atoms that are in a metastable state. This collision results in the stimulated emission of several photons by the Neon atoms. This event occurs repeatedly and is responsible for the laser phenomenon; Light Amplification by Stimulated Emission of Radiation. Further photon collisions cause increased coherent emission. These chain reactions, ultimately create an in-phase, or coherent light energy level which is sufficient to generate a beam through the laser tube aperture.

3-8. The laser frequency is determined by the transition between energy levels of the Neon atoms. The distance between mirrors establishes a cavity length which is adjusted to support longitudinal oscillations at a wavelength of 6328 Angstroms (5×10^{14} Hz). This wavelength lies in the red region of the visible light spectrum.

3-9. A small amount of resonant cavity length tuning is provided by the piezoelectric transducer (PZT) which is in front of the rear mirror. A spring behind the mirror forces it against the PZT. The PZT has the property of expanding in a thickness which is proportional to the amount of positive dc voltage applied through a stem connection at the rear of the tube. The expanding PZT pushes the mirror to the rear of the tube, thereby creating a longer resonant cavity. The longer cavity sustains oscillations at a slightly lower frequency. Therefore, the laser tube responds to a more positive PZT voltage by tuning to a slightly lower frequency. Conversely, the tube responds to a less positive PZT voltage by tuning to a higher laser frequency. This PZT control potential ranges from +270V to +1800V.

3-10. A magnet that surrounds the laser tube causes Zeeman splitting of its frequency symmetrically about f_0 , the normal laser center frequency. This results in two circularly polarized frequency components existing in the same beam. One component is left-hand circularly polarized (LHCP) and is approximately 1 MHz from the center operating frequency of the tube (f_0). The other beam frequency component is right-hand circularly polarized (RHCP) and is approximately 1 MHz from f_0 in the other direction.

3-11. The laser beam, containing the two circularly polarized frequency components (f_1 and f_2), passes through a $\lambda/4$ plate (λ = wavelength). This causes the f_1 and f_2 components to become linearly polarized and mutually perpendicular, or orthogonal. These frequency components then pass through a $\lambda/2$ plate which is factory-adjusted to compensate for the imperfect orthogonal positioning of the f_1 and f_2 signals.

3-12. The laser beam, containing the vertically polarized f_1 (the lower of the two frequencies) and the horizontally polarized f_2 components, passes through a collimating telescope. This device consists of a compound lens which spreads the extremely narrow laser beam into a parallel 0.28 inch (7 mm) output beam.

3-13. A device called a beam splitter diverts a small portion of the output beam and routes this sample to a polarizing beam splitter. This splitter partially separates and applies the f_1 and f_2 signals to the PZT control circuit. The PZT control circuit compares the signal level of the f_1 and f_2 samples. If the levels of these samples are not equal, an appropriate (dc) PZT control voltage is generated to tune the laser tube and cause equalization of the f_1 and f_2 components. In addition to providing this automatic tuning control, the control circuits extract the difference frequency between f_1 and f_2 and generate an electrical reference measurement signal for use by the transducer accessory equipment.

3-14. Additional circuits within the laser head monitor PZT voltage, laser current, and performance of the automatic tuning circuits, as well as external operating power inputs. These circuits drive fault lights and provide diagnostic signals to accessory equipment. A retune command signal, from accessory equipment or manually activated at the laser head, interrupts the automatic PZT tuning and forces the laser to tune to the center of its mechanical range for 3 seconds. Control is then returned to the automatic control circuits. This retune capability is provided to bring the laser operating frequency within the range of automatic control when, due to extreme environmental changes, the laser attempts to tune beyond the automatic tuning range.

3-15. GENERAL FUNCTIONAL DESCRIPTION

3-16. The following text provides a detailed functional analysis of laser head operation. All descriptions relate to Figure 7-4 unless otherwise specified. Operation of the laser head can be grouped into the following functions:

- Power Distribution
- Laser Current Regulation
- Automatic (PZT) Tuning
- Control and Diagnostic Monitoring

3-17. Power Distribution

3-18. When +15 Vdc and -15 Vdc are applied to the laser head, the POWER ON light-emitting-diode indicator (on the A1 Connector Board) is forward biased and illuminates. The dc input potentials also produce a virtual ground level at the junction of two 15K ohm resistors. This balanced condition results in an open circuit at both outputs of the comparator switch. An unbalanced condition exists when either the positive or negative dc input deviates from 15 volts by approximately 1 volt or more. This offset causes a corresponding comparator switch output to go to ground, resulting in a lit UNBAL indicator. Table 3-1 lists the unbalanced dc voltage conditions and the resulting unbalanced indications.

Table 3-1. DC Unbalanced Failures

DC Input Voltage	Unbalanced Condition (See Note)	Unbalanced Indicators	
		+15V UNBAL	-15V UNBAL
+15 Vdc	High (more positive)	ON	OFF
	Low (less positive)	OFF	ON
-15 Vdc	High (more negative)	OFF	ON
	Low (less negative)	ON	OFF

3-19. If either the +15 Vdc or -15 Vdc two-amp fuse opens, current is diverted through the associated LED indicator, turning that fuse indicator on.

3-20. System operating power is distributed to the laser head and other transducer units via the connector board. Safety switch S2 opens when the laser head cover is removed. This disconnects -15 Vdc from the piezoelectric transducer (PZT) power supply and the high voltage power supply. As a result, these power supplies become inoperative. The +15 Vdc input is applied to a regulator on the A7 Control Board. This regulator provides +5 volts for use within the laser head.

NOTE

High or low indicates voltage deviation of approximately 1 volt, or more. For example, consider the +15 volt input going more positively by 1 volt. The inverted input to the comparator switch goes high (i.e., more positive than ground). This results in the cathode of LED D51 switch going to ground, activating the UNBAL +15V Indicator. The cathode of LED D52 output remains open. Conversely, if the -15 volt input goes more negative by approximately 1 volt, the unbalance condition causes the comparator switch inverted input to go negative, grounding the cathode of D52 and opening the D51 cathode. As a result, the -15V unbalance indicator is lit.

3-21. Laser Current Regulation

3-22. The laser current regulation circuit is a control loop consisting of an error sensing circuit and the high voltage power supply. A 390 ohm resistor on the A1 Connector Board provides a current path for the laser tube cathode. The resulting voltage drop across this resistor provides a monitoring input to a difference amplifier on the Connector Board. This difference amplifier functions as a voltage comparator. The other comparator input is a reference voltage which is determined by the adjustment of potentiometer A1R11. Laser current is adjusted by monitoring A7TP2 (i.e., the laser cathode current test point on the Control Board) or A1TP1 (adjacent to A1R11) and setting A1R11 for the appropriate reading. Once set, any change in laser current results in a comparator error output signal. This error signal changes the conduction of driver A1Q3. Transistor A1Q3 drives a series regulator Q1, which acts as a variable resistance to control the amount of drive to the High Voltage Power Supply A2.

3-23. The A2 High Voltage Power Supply consists of an oscillator and a high voltage multiplier circuit. The oscillator is activated when -15 volts is supplied via safety switch A1S2. Oscillation is maintained by internal switching transistors that alternately drive magnetic core transformer T1 in and out of saturation at a rate that depends on the amount of voltage delivered by series regulator Q1. Higher drive voltage results in a higher oscillator frequency and a higher peak-to-peak amplitude. Less voltage reduces oscillator frequency and amplitude. The typical oscillator output range is 12.5 kHz at 50 volts (peak-to-peak) to 25 kHz at 125 volts (peak-to-peak). The oscillator output signal determines the amount of high voltage dc output that is produced by the high voltage multiplier circuit.

3-24. The high voltage multiplier consists of voltage doubler circuits that are wired in series to produce a net high voltage output of up to 10K Vdc. This variable output is applied to the anode of the laser tube to control tube current. The high voltage circuit responds to a variation in cathode current by providing a change in anode high voltage. This high voltage change brings laser tube current back to the appropriate level.

3-25. Automatic PZT Tuning

3-26. The laser tube is automatically fine tuned by a control loop, which consists of the Beam Splitter Assembly (A4), Lock Reference Assembly (A5), and the PZT Power Supply Assembly (A6). These circuits sample the output beam and provide PZT control voltages that maintain the appropriate dual-frequency beam emission.

3-27. The Beam Splitter Assembly diverts approximately 20% of the laser tube output beam and applies this portion of the beam to a polarized beam splitter. The polarized splitter extracts the orthogonal frequency components from the beam sample and provides separated f₁ and f₂ frequency inputs to the Lock Reference Assembly photodetector diodes.

3-20. The polarized beam splitter allows a small portion of the f_1 component to be mixed with the f_2 photodiode input. A small amount of f_1 signal is also combined with the f_2 photodiode sample. As a result, each photodiode detects a difference frequency signal (approximately 2 MHz). One photodiode output signal, designated comp- f_1 , consists of a dominant f_1 signal, and a small amount of f_2 . As a result the amplitude of the comp- f_1 signal is a function of the f_1 component of the beam sample. The comp- f_1 amplitude is determined by the f_1 level of the input beam sample. Comp- f_1 is applied to the negative difference integrator input, while comp- f_2 is applied to the positive input. The difference integrator compares these inputs and provides a resultant negative dc output signal. The magnitude of this signal depends on the relative amplitude of the comp- f_1 and comp- f_2 signals. Typical levels range from -3 Vdc to -7 Vdc.

3-29. The FREQ potentiometer, A5R4, is an offset adjustment that provides the appropriate difference integrator output when equal comp- f_1 and comp- f_2 signals are applied. This adjustment compensates for the fact that the two photodiodes are not perfectly matched.

3-30. A RETUNE CLAMP input signal from the A7 Control Assembly activates the clamp switch circuits; this results in a -6 volts difference integrator output. This RETUNE CLAMP signal is provided when the manual RETUNE button is pressed or when the RETUNE CMD signal is received. The clamp signal lasts 3 seconds, after which time the automatic circuits resume control of the difference integrator output.

3-31. The dc difference integrator control signal is applied through an emitter follower to the PZT Power Supply. The PZT Power Supply operates in a manner similar to the High Voltage Power Supply and consists of an oscillator and one voltage doubler. This power supply responds to control input by providing a dc output that varies from 1 to 2 kV. This output directly controls the laser tube PZT, and ultimately causes equalization of the laser beam f_1 and f_2 frequency components.

3-32. To demonstrate PZT control loop operation, consider an f_0 (center frequency) drift towards a lower frequency (f_1). The resulting increase in f_1 signal level is sensed by the Lock Reference Assembly circuits. These circuits respond by applying a more negative PZT control signal to the PZT Power Supply, causing a PZT voltage decrease. The tuned laser tube frequency is inversely proportional to PZT control voltage input. A decreasing PZT voltage therefore tunes the laser tube towards a higher frequency. As a result, the f_1 amplitude decreases and the f_1 component becomes equal to the f_2 component signal level.

3-33. The Lock Reference Assembly also performs the function of providing the system with a reference signal. The comp- f_2 signal is applied to an over-driven RF amplifier. The resulting output is applied to a differential line driver and a detector circuit. The detector provides a dc signal which is proportional to the RF comp- f_2 signal strength. When this dc output signal exceeds +0.3 volt, a sufficient signal requirement is satisfied. As a result, the threshold detector output goes high enabling the differential driver which produces a true REF OK signal. The enabled driver provides complementary (REF and REF) reference signals to the transducer accessory modules.

3-34. Control and Diagnostic Monitoring

3-35. The A6 Control Assembly generates diagnostic signals and provides timing and control signals for the retune function.

3-36. RETUNE FUNCTION (refer to Figure 3-1 and 7-4). The retune function is initiated when the RETUNE pushbutton, S1, is depressed or an external RETUNE CMD signal is received from a transducer controller. The high-to-low transition of this signal clears the tune fault latch and sets the tune latch on the Control Board. The tune latch then provides a low RETUNE output signal that activates the error gate, resulting in a true (high) ERROR diagnostic output signal. The logic high RETUNE signal, (also generated by the tune latch) provides drive that lights the RETUNE LED indicator. The ERROR diagnostic signal stays high and the RETUNE indicator remains lit during the complete retune cycle. If the laser head successfully retunes, the ERROR signal goes low and the RETUNE indicator goes out.

3-37. At time t_1 (the positive transition of the RETUNE CMD signal) the retune timing circuits generate a 3-second RETUNE CLAMP signal which is applied to the Lock Reference Assembly. The Lock Reference Assembly tuning circuits respond to this input by ultimately driving the PZT-controlled laser frequency towards center (f_0). Upon termination of the RETUNE CLAMP signal (3 seconds after t_1), the automatic PZT tuning circuits resume control of the laser tuning. Successful retuning is accomplished when the comp- f_1 input signal to the Lock Reference Assembly provides proportional dc drive that exceeds a +0.3 Vdc threshold level. When this condition is satisfied, a low REF OK signal is generated. This signal is applied to the Control

Assembly test gate, inhibiting the gate. This disabled gate prevents a set signal (generated during time t_1) from reaching the fault latch. As a result, the fault latch remains cleared and provides a low enable signal to the clear gate. During time t_3 (approximately 9 seconds after the retune cycle started), a 10-microsecond CLR signal is inverted by the enabled clear gate and the resulting CLR trigger clears the tune latch.

3-30. If the retuning process is not successfully accomplished, the threshold detector output (on the Lock Reference Assembly) remains low. This signal prevents generation of a system reference signal and provides a false (high) REF OK signal. This high signal enables the test gate (on the Control Assembly) during times t_1 to t_3 . As a result, the t_1 signal (from the retune timing circuits) drives the test gate output low. This low signal sets the tune fault latch. The set latch:

- Provides drive to light the RETUNE FAILURE LED indicator.
- Inhibits the clear gate; thereby keeping the tune latch set. As a result the RETUNE LED indicator remains ON.
- Maintains an active (high) ERROR output signal.

3-39. **DIAGNOSTIC SIGNALS AND INDICATORS.** Improper laser current, PZT voltage or beam sampling inputs results in an active (high) diagnostic ERROR output signal. The laser cathode resistor on the Connector Board provides an input voltage which serves as a monitoring signal to the Control Board Laser Current Fault Detector. This fault detector is a dual comparator which is activated when the monitoring voltage (representing laser current) exceeds an upper limit of +2.0 volts, or falls below the lower limit of +1.0 volt. The resulting low LI FAULT signal activates the error gate, turns the LASER CURRENT fault indicator on, and provides a subsystem LASER CURRENT fault diagnostic output signal.

3-40. A part of the PZT Power Supply output voltage (approximately 1/1000th) is sampled and applied to the PZT fault detector on the Control Assembly. This circuit is also a dual comparator which is activated when the PZT sample input exceeds +1.8 volts, or falls below +0.27 volt. A low PZT output signal sets the tune latch activating the ERROR diagnostic output signal. In addition, the set tune latch output lights the RETUNE Indicator and provides an active RETUNE diagnostic output signal. This signal indicates a laser retune requirement.




Figure 3-1. Retune Timing Diagram

MAINTENANCE

SECTION IV MAINTENANCE

4-1. INTRODUCTION

4-2. This section provides information to facilitate 5501A laser head maintenance at the replaceable module level. Included are performance checks, instrument access procedures, a troubleshooting flow chart, troubleshooting diagrams, and adjustment procedures. When a faulty module is isolated, the trouble may be further isolated to the component level by using the functional theory provided in Section III of this manual.

4-3. PERFORMANCE CHECK

4-4. When a new 5501A is received, or normal operation is in doubt, this test may be performed to determine if the unit is operating properly. The +15 Vdc and -15 Vdc are derived from external power supplies. If necessary, adjust these power supplies to conform to parameters in Tables 4-1 and 4-2. The following test equipment is recommended:

HP 1707 Oscilloscope or equivalent (2 MHz measurements)

HP 5300/5306 Multimeter/Counter (+15V measurements)

4-5. Check the 5501A voltages in the following manner:

- Disconnect the POWER cable,
- Measure the voltages at the disconnected cable plug as outlined in Table 4-1.

Table 4-1. Input Voltage

Plug Pin	Voltage
A(+), D(-)	+15 $\pm$ 0.25V
D(+), B(-)	-15 $\pm$ 0.25V

- Connect the plug to the 5501A POWER connector. Disconnect the DIAGNOSTIC plug and perform the voltage measurements according to Table 4-2.

Table 4-2. Voltages at Diagnostic Connector

DIAGNOSTIC Connector Pin	Voltage
A(+), D(-)	+15V $\pm$ 1V
D(+), B(-)	-15V $\pm$ 1V
C(+), D(-)	*+15V $\pm$ 0.25V

*Voltage provided by 5501A circuits.

- d. Observe the rear-panel indicators of the 5501A while depressing, then releasing, the RETUNE switch. The indicators should be as described in Table 4-3.

Table 4-3. Indicator Conditions During Retune

Indicator	Condition
+15V UNBAL.	OFF
-15V UNBAL.	OFF
+15V FUSE	OFF
-15V FUSE	OFF
POWER ON	ON
LASER CURRENT	OFF
RETUNE FAILURE	If on, should go off after RETUNE switch is depressed.
RETUNE	Light goes off approximately 9 seconds after switch is released.

- e. Disconnect plug to 5501A REFERENCE SIGNAL connector and check for a proper signal as shown in Table 4-4.
- f. Reconnect all cables and observe red beam emitted from 5501A. DO NOT STARE DIRECTLY INTO BEAM.

Table 4-4. Reference Signal

Reference Signal Connector Pin	Signal
C	
D	

4-6. INSTRUMENT ACCESS

- 4-7. Access to the assemblies within the laser head is required to troubleshoot or adjust the laser head circuits. The following paragraphs describe how to remove the laser head covers and how to remove and reinstall the major assemblies.

WARNING.

HIGH VOLTAGES ARE GENERATED WITHIN THE LASER HEAD HOUSING. THE COVER OF THE LASER HEAD CONTROLS A SAFETY INTERLOCK SWITCH TO PREVENT ACCIDENTAL ACCESS TO THESE VOLTAGES; TO ENSURE SAFETY AND POSSIBLE EQUIPMENT DAMAGE, HOWEVER, ALWAYS DISCONNECT THE POWER SOURCE FROM THE LASER HEAD BEFORE REMOVING THE COVERS.

- 4-8. To remove the front panel and side covers from the laser head, perform the following steps:
- Rotate the front-panel turret so that the large opening is at the bottom and the slotted, 1/4-turn fastener is visible through the opening.
 - Using a suitable screwdriver, rotate the fastener 1/4-turn in the counterclockwise direction.
 - Remove the front panel by gently pulling the panel straight away from the laser head.
 - Remove the two half-covers by gently pulling each cover outward and forward. This releases the edges of the covers from the retaining grooves along the edges of the rear panel.
- 4-9. To remove the A5 Lock Reference Board Assembly, perform the following steps:
- Remove the two machine screws that secure the lock reference board to the A4 Beam Splitter Assembly. These two screws also retain the circular shroud that covers the two photodiodes mounted on the board.
 - Remove the two machine screws that secure the lock reference board to the U-shaped, sheet-metal sub-panel.
 - Gently remove the board from the mating connector.
- 4-10. To remove the A7 Control Board Assembly, perform the following steps:
- Remove the two machine screws that secure the control board to the U-shaped, sheet-metal sub-panel.
 - Gently remove the board from the mating connector.
- 4-11. To remove the A1 Connector Board Assembly, perform the following steps:
- Remove the four machine screws that secure the rear panel and remove the panel.
 - Remove the two machine screws that mount the connector board to the cast base plate of the unit.
 - Label and remove the eight wires that connect to the back side of the connector board. These wires use separate pin connectors and should be disconnected by gently pulling the wires straight away from the connector board.
 - Remove the two machine screws and nuts that attach the 21-pin, molded-plastic connector to the connector board and remove the connector board.
- 4-12. Remove the laser tube according to the following procedure:

WARNING

THE FOLLOWING PROCEDURE REQUIRES THE REMOVAL OF HIGH VOLTAGE POWER CONNECTIONS FROM THE LASER TUBE. IT IS POSSIBLE FOR SOME VOLTAGE POTENTIAL TO REMAIN ON THESE CONNECTIONS, AND IF THE POTENTIAL IS NOT DISCHARGED ACCORDING TO THE FOLLOWING PROCEDURE, INJURY TO SERVICE PERSONNEL CAN RESULT.

- Disconnect the high voltage power supply connection from the laser tube by rotating the white, knurled fastener in the counterclockwise direction; hold the wire from rotating with the fastener. **DO NOT TOUCH THE SPRING-LOADED CONTACT.**
- Momentarily place the spring-loaded high voltage contact on a suitable power supply return point such as the cast base plate on which the laser tube is mounted.
- Remove the laser tube cathode connection (located on the side of the glass portion of the laser tube) by pulling the connector cap straight away from the laser tube.
- Place the laser head on its side and, while supporting the tube with one hand, remove the four tube mounting screws, which are accessible from the bottom of the cast base plate. When installing the laser tube, tighten the two countersunk, crosspoint screws first, then tighten the two allen head cap screws. This ensures that the laser tube is properly aligned.
- Gently remove the laser tube far enough to disconnect the PZT anode lead, which is located at the rear center of the tube, then remove the tube.

- 4-13. Remove the A6 PZT Power Supply Assembly according to the following procedure:

WARNING

THE FOLLOWING PROCEDURE REQUIRES THE REMOVAL OF HIGH VOLTAGE POWER CONNECTIONS FROM THE LASER TUBE. IT IS POSSIBLE FOR SOME VOLTAGE POTENTIAL TO REMAIN ON THESE CONNECTIONS, AND IF THE POTENTIAL IS NOT DISCHARGED ACCORDING TO THE FOLLOWING PROCEDURE, INJURY TO SERVICE PERSONNEL CAN RESULT.

- a. Remove the A1 Connector Board Assembly as previously described in this section of the manual.
- b. Disconnect the PZT anode connection from the rear of the laser tube. DO NOT TOUCH THE METAL TIP OF THE CONNECTOR.
- c. Momentarily place the metal connector tip to a suitable power supply return point such as the cast base plate on which the laser tube is mounted. This will remove the possibility of a shock hazard from the anode lead.
- d. Remove the three recessed machine screws (from the top) that secure the PZT power supply to the cast base plate, and remove the power supply from the unit.

- 4-14. Remove the A2 High Voltage Power Supply Assembly according to the following procedure:

WARNING

THE FOLLOWING PROCEDURE REQUIRES THE REMOVAL OF HIGH VOLTAGE POWER CONNECTIONS FROM THE LASER TUBE. IT IS POSSIBLE FOR SOME VOLTAGE POTENTIAL TO REMAIN ON THESE CONNECTIONS, AND IF THE POTENTIAL IS NOT DISCHARGED ACCORDING TO THE FOLLOWING PROCEDURE, INJURY TO SERVICE PERSONNEL CAN RESULT.

- a. Remove the high voltage power supply connector from the laser tube by rotating the white, knurled fastener in the counterclockwise direction; hold the wire from rotating with the fastener. DO NOT TOUCH THE SPRING-LOADED CONTACT.
- b. Momentarily place the spring-loaded high voltage contact to a suitable power supply return point such as the cast base plate on which the laser tube is mounted.
- c. Disconnect the three remaining power supply leads from the pin connectors on the A1 Connector Board Assembly.
- d. Using a suitable allen wrench, loosen the three screws on each forward side of the cast base plate. These screws secure the U-shaped, sheet-metal sub-panel in a retaining groove at the front of the cast base plate.
- e. Carefully lift and rotate the U-shaped sub-panel (with circuit board assemblies attached) until it can be gently rested on top of the laser tube.
- f. Remove the two recessed machine screws (from the top) that attach the high voltage power supply to the cast base plate.
- g. Remove the encapsulated power supply module from the unit.

4-15. TROUBLESHOOTING

4-16. If the 5501A fails any part of the performance check or an operational failure occurs, use the Troubleshooting Flow Chart (Figure 4-1) to isolate the failure to the faulty module. Further fault isolation to the component level may then be accomplished by referring to the functional diagram of Figure 7-4 and the accompanying theory in Section III. In the Troubleshooting Flow Chart (Figure 4-1), adjustment procedures are referenced when required. The module location and schematic diagrams (in Section VII of this manual) are also provided to help the troubleshooter.






Figure 4-1. Troubleshooting Flow Chart



Items listed in order of most probable cause of failure:

- ①
 - a. Check -15V input.
 - b. Check Fuse F2.
 - c. Check that safety switch S2 is engaged and functioning correctly.
- ②
 - a. Check A2 High Voltage Power Supply.
 - b. If A2 is replaced, perform laser current adjustment.
- ③
 - a. Check Q1 series regulator.
 - b. If replaced, perform laser current adjustment.
- ④
 - a. Check A1 connector board assembly.
 - b. If replaced, perform laser current adjustment.
- ⑤
 - a. Check A3 laser tube.
 - b. Perform laser current adjustment.
 - c. Perform reference threshold adjustment.

Figure 4-2. Laser Current Loop Failure Analysis



Items listed in order of most probable cause of failure:

- ①
 - a. Check PZT Power Supply by measuring +0.27V to +1.0V at A7(TP2).
 - b. Replace power supply if readings are incorrect.
- ②
 - a. Check/Replace A5 Lock Reference Board Assembly.
 - b. Perform reference threshold adjustment.
 - c. Perform photo-diode off-set adjustment.
- ③
 - a. Check/Replace A3 Laser Tube Assembly.
 - b. Perform laser current adjustment.
 - c. Perform reference threshold adjustment.
- ④
 - a. Replace A5 Lock Reference Assembly.
 - b. Perform reference threshold adjustment.

Figure 4-3. Automatic Retune Loop Failure Analysis

Table 4-5. Module Adjustment Requirements

Module Replaced	Adjustment Required
A1 Connector Board	Laser Current Adj.
A2 High Voltage Power Supply	Laser Current Adj.
A3 Laser Tube Assembly	Laser Current Adj., Reference Threshold Adj.
A4 Beam Splitter Assembly	Reference Threshold Adj.
A5 Lock Reference Board	Reference Threshold Adj., Photodiode Off-set Adj.
A6 PZT Power Supply	Reference Threshold Adj.

4-17. ADJUSTMENT PROCEDURES

4-18. The Lock Reference Board Assembly (05501-60204) and the Connector Board Assembly (05501-60201) are the only 5501A field-adjustable modules. Perform the adjustment procedures either as a troubleshooting check or when certain modules are replaced. Table 4-5 lists the 5501A modules and the adjustment requirements that result from replacement of these modules.

4-19. Lock Reference Board Adjustments

4-20. Two adjustments are performed on the A5 Lock Reference Board Assembly: the reference threshold adjustment, and the photodiode offset adjustment.

4-21. **REFERENCE THRESHOLD ADJUSTMENT.** Perform the reference threshold adjustment when troubleshooting the laser head or when any of the following assemblies are replaced:

- A3 Laser Tube Assembly
- A4 Beam Splitter Assembly
- A5 Lock Reference Board Assembly
- A6 PZT Power Supply Assembly

4-22. The recommended test equipment is:

- HP 1707 Oscilloscope or equivalent (ac noise measurements)
- HP 5300/5306 Multimeter/Counter (dc voltage measurements)

NOTE

Since the laser head covers are removed, the connector board safety switch, A152, must be closed for the laser head to operate.

4-23. Make the adjustment according to the following procedure (refer to Figure 4-4):

- a. Block laser beam as shown in Figure 4-5.
- b. Measure peak-to-peak ambient noise at A5TP3 with oscilloscope.
- c. Divide this peak-to-peak value by two.
- d. Measure static dc level at A5TP7 with oscilloscope or voltmeter.
- e. Record the larger of the values obtained in steps c and d.
- f. Monitor A5TP8 with a DVM or oscilloscope, and adjust the threshold potentiometer, A5R42, for a dc voltage equal to twice the value recorded in step e (see Figure 4-4).




Figure 4-4. A5 Lock Reference Board Adjustment Locations




Figure 4-5. Laser Beam Blocking Method

- b. Remove beam obstruction (inserted in step a).
- h. Depress RETUNE pushbutton. Proper indications are:
 - 1) RETUNE FAILURE Indicator extinguishes immediately.
 - 2) RETUNE Indicator goes out nine seconds after switch is depressed.

4-24. **PHOTODIODE OFFSET ADJUSTMENT.** This adjustment must be performed when the Lock Reference Board Assembly is replaced. The HP 5300/5306 (2 MHz frequency counter capability) or equivalent is recommended. (An oscilloscope can also be used to measure the 2 MHz signal by expanding the horizontal scale.)

4-25. Make the adjustment according to the following procedure (refer to Figure 4-4):

- a. Connect counter probe to A5TP6.
- b. Adjust A5R4 for maximum frequency (or minimum period if an oscilloscope is used).

4-26. Laser Tube Current Adjustment

4-27. Although all laser tubes appear to be identical, each has a slightly different current rating. Adjusting the laser current regulator circuits for the correct current ensures optimum tube operation and output beam bandwidth.

4-28. Perform the laser current adjustment when the laser tube is operating improperly (i.e., flashing on and off) or when any of the following are replaced:

- A1 Connector Board Assembly
- A2 High Voltage Power Supply Assembly
- A3 Laser Tube Assembly
- A1 chassis-mounted 5.125 regulator

4-29. Recommended Test Equipment:

HP 5300/5306 Multimeter/Counter (dc voltage measurement)

4-30. This procedure is performed by adjusting the current regulator circuit while monitoring voltage across the laser tube cathode resistor, A1R16 (refer to Figure 4-6). The regulator circuits and the cathode resistor are mounted on the A1 Connector Board Assembly. The voltage across the 390-ohm cathode resistor is determined by the laser tube current. Therefore the correct voltage is calculated by multiplying the rated tube current by 390. Adjust current as follows:

NOTE

Since the laser head covers are removed, the safety switch, A1S2 (located on the connector board), must be actuated for the laser current circuits to operate.

- a. Read the rated current stamped on the tube plate (this value is typically 2.6 mA to 5.1 mA).
- b. Multiply this value by 390 (calculated value is typically 1.0 to 2.0 volts).
- c. While monitoring the laser current test point, adjust the laser current potentiometer, A1R11, for the value obtained in step b.




Figure 4-6. Laser Current Adjustment Locations

PARTS LIST

SECTION V REPLACEABLE PARTS

5-1. INTRODUCTION

5-2. This section contains information for ordering replacement parts. Table 5-1 lists parts in alphanumeric order of reference designations and provides the following information on each part:

- Hewlett-Packard part number.
- Description of part (see abbreviations below).
- Total quantity used in the instrument. (The total quantity appears after the first entry for a given part.)
- Typical manufacturer of the part in a five-digit code (see list of manufacturers in Table 5-2).
- Manufacturer's part number.

5-3. Miscellaneous parts are listed at the end of Table 5-1.

5-4. ORDERING INFORMATION

5-5. To obtain replacement parts, address order to your local Hewlett-Packard Sales and Service Office listed at the back of this manual. Identify parts by their Hewlett-Packard part number. To obtain a part that is not listed, include:

- Instrument model number.
- Instrument serial number.
- Description of the part.
- Function and location of the part.

REFERENCE DESIGNATIONS

A	• assembly	B	• miscellaneous electrical part	HP	• miscellaneous mechanical part	TP	• test point
AT	• attenuator, isolator, termination	F	• fuse	P	• electrical connector (movable portion); plug	IC	• integrated circuit; microcircuit
C	• fan; motor	FL	• filter	Q	• transistor, SCR; thyristor	V	• electron tube
CP	• capacitor	HV	• hardware	R	• resistor	VR	• voltage regulator; breakdown diode
CN	• coupler	J	• electrical connector (stationary portion); jack	RT	• thermistor	W	• cable; transmission path; wire
DC	• diode; diode thyristor; varactor	K	• relay	S	• switch	X	• socket
DL	• directional coupler	L	• coil; inductor	T	• transformer	Y	• crystal unit; piezo-electric
DS	• delay line	M	• meter	TD	• terminal board	Z	• tuned cavity; tuned circuit
	• annunciator; signaling device (audible or visual); lamp; LED			TC	• thermocouple		

ABBREVIATIONS

A	• ampere	BCD	• binary coded decimal	COMP	• composition	°K	• degree Kelvin
ac	• alternating current	BD	• board	COMPL	• complete	DEFC	• deposited carbon
ACCESS	• accessory	BE CU	• beryllium copper	CONN	• connector	DET	• detector
ADJ	• adjustment	BFO	• beat frequency oscillator	CP	• cadmium plate	diam	• diameter
A/D	• analog-to-digital	BH	• binder head	CRT	• cathode ray tube	DIA	• diameter (used in parts list)
AF	• audio frequency	BDN	• breakdown	CTL	• complementary transistor logic	DIFF	• differential amplifier
AFG	• automatic frequency control	BP	• bandpass	CW	• continuous wave	AMPL	• amplifier
AGC	• automatic gain control	RPF	• bandpass filter	cw	• clockwise	div	• division
AL	• aluminum	DRS	• brass	D/A	• digital-to-analog	DPDT	• double-pole, double-throw
ALO	• automatic level control	DWO	• backward-wave oscillator	dB	• decibel referred to 1 mW	DR	• drive
AM	• amplitude modulation	CAL	• calibrate	dBm	• decibel	DSB	• double sideband
AMPL	• amplifier	CW	• counterclockwise	dc	• direct current	DTL	• diode transistor logic
APC	• automatic phase control	CEN	• ceramic	deg	• degree (temperature interval or difference)	JVM	• digital voltmeter
ASSY	• assembly	CHN	• channel	°C	• degree Celsius (centigrade)	ECL	• emitter coupled logic
AUX	• auxiliary	CM	• centimeter	°F	• degree Fahrenheit	EMF	• electromotive force
avg	• average	CNO	• coaxial			EDP	• electronic data processing
AWG	• American wire gauge	COEF	• coefficient			ELECT	• electrolytic
BAL	• balance	COM	• common				

ABBREVIATIONS (CONTINUED)

ENCAP	• encapsulated	min	• minute (time)	PIV	• peak inverse voltage	TFT	• thin-film transistor
BAT	• external	MINAT	• minute (plane angle)	PK	• peak	TGL	• toggle
F	• farad	mm	• millimeter	PL	• phase lock	THD	• thread
FDT	• fluid-effect transistor	MOD	• modulator	PLO	• phase lock oscillator	THRU	• through
FIF	• flip-flop	MOM	• momentarily	PM	• phase modulation	TI	• titanium
FI	• flat head	MOS	• metal-oxide semi-conductor	PNP	• positive-negative-positive	TOL	• tolerance
FOL H	• filter head	ma	• milliamperes	PNO	• part of	TRM	• trimmer
FM	• frequency modulation	MIL	• mil	POLY	• polystyrene	TRN	• transistor
FP	• front panel	MTN	• meter (indicating device)	PORG	• porcelain	TRL	• transistor-transistor logic
FREQ	• frequency	mV	• millivolt	POS	• positive; position(s)	TV	• television
FSD	• fixed	mVac	• millivolt, ac	POSH	• position	TVI	• television interference
G	• gram	mVdc	• millivolt, dc	PQT	• potentiometer	TWT	• traveling-wave tube
GE	• germanium	mVpk	• millivolt, peak	P-P	• peak-to-peak	U	• micro (10 ⁻⁶) (used in parts list)
GHZ	• gigahertz	mVp-p	• millivolt, peak-to-peak	PFM	• pulse-position modulation	UF	• microfarad (used in parts list)
GL	• glass	mVrms	• millivolt, rms	PREF	• preamplifier	UIF	• ultrahigh frequency
GND	• grounded	mW	• milliwatt	PRF	• pulse-repetition frequency	UNREG	• unregulated
H	• henry	MUX	• multiplex	PT	• pulse repetition rate	V	• volt
HET	• heterodyne	MY	• mylar	PTM	• pulse-time modulation	VA	• voltampere
HGX	• hexagonal	µA	• microampere	PWM	• pulse-width modulation	Vac	• volts ac
HD	• head	µA	• microampere	PWV	• peak working voltage	VAR	• variable
HDW	• hardware	µho	• microhm	Q	• quality factor	VCO	• voltage-controlled oscillator
HF	• high frequency	µs	• microsecond	Q	• quality factor	Vdc	• volts dc
HG	• mercury	µV	• microvolt	Q	• quality factor	VDCW	• volt, dc, working (used in parts list)
HI	• high	µVac	• microvolt, ac	RECT	• rectifier	V(F)	• volts, filtered
HIP	• high pressure	µVdc	• microvolt, dc	REF	• reference	VFO	• variable-frequency oscillator
HIF	• high pass filter	µVpk	• microvolt, peak	REG	• regulated	VHF	• very-high frequency
HN	• hour (used in parts list)	µVp-p	• microvolt, peak-to-peak	REPL	• replaceable	Vpk	• volts peak
HV	• high voltage	µVrms	• microvolt, rms	RF	• radio frequency	Vp-p	• volts peak-to-peak
Hz	• hertz	µW	• microwatt	RFI	• radio frequency interference	Vrms	• volts rms
IC	• integrated circuit	NA	• no connection	RH	• round head, right hand	VSWR	• voltage standing wave ratio
ID	• inside diameter	NC	• normally closed	RLO	• resistance-inductance-capacitance	VTO	• voltage-tuned oscillator
IF	• intermediate frequency	N/C	• normally closed	RMC	• rack mount only	VTM	• vacuum-tube voltmeter
IMP	• impedance	NE	• negative	RND	• round	V(X)	• volts, switched
IN	• inch	NEG	• negative	RPM	• revolutions per minute	W	• watt
INCD	• incandescent	NF	• nanofarad	RQ	• resistor only	W	• watt
INCL	• include(s)	N/O	• normally open	RST	• reset	W	• watt
INP	• input	NOM	• nominal	RW	• reverse working voltage	WV	• working inverse voltage
INS	• insulation	NORM	• normal	RWV	• reverse working voltage	WV	• working inverse voltage
INT	• internal	NTH	• negative-positive-negative	S	• second (time)	WV	• working inverse voltage
IP	• bipolar	NTP	• not recommended for field replacement	S-B	• second (plane angle)	WV	• working inverse voltage
IZ	• impedance	NSI	• not separately replaceable	S-C	• silicon controlled rectifier, screw	WV	• working inverse voltage
LA	• lithium	ns	• nanosecond	SE	• selenium	WV	• working inverse voltage
LV	• low voltage	nW	• nanowatt	SECT	• section	WV	• working inverse voltage
LY	• low frequency	OB	• order by description	SEMICON	• semiconductor	WV	• working inverse voltage
LO	• long	OD	• outside diameter	SHF	• superhigh frequency	WV	• working inverse voltage
LH	• left hand	OH	• ohm	SI	• silicon	WV	• working inverse voltage
LIM	• limit	OP AMP	• operational amplifier	SIL	• silver	WV	• working inverse voltage
LIN	• linear	OPT	• option	SL	• slide	WV	• working inverse voltage
LK WAS	• lock washer	OSC	• oscillator	SHI	• signal-to-noise ratio	WV	• working inverse voltage
LO	• low; local oscillator	OX	• oxide	SPDT	• single-pole, double-throw	WV	• working inverse voltage
LOG	• logarithmic taper (used in parts list)	oz	• ounce	SPG	• spring	WV	• working inverse voltage
log	• logarithmic	Ω	• ohm	SR	• split ring	WV	• working inverse voltage
LPF	• low pass filter	P	• peak (used in parts list)	SPST	• single-pole, single-throw	WV	• working inverse voltage
LV	• low voltage	PAM	• pulse-amplitude modulation	SSB	• single sideband	WV	• working inverse voltage
m	• meter (distance)	PC	• printed circuit	SBY	• standby	WV	• working inverse voltage
MA	• milliampere	PCM	• pulse-code modulation	STL	• steel	WV	• working inverse voltage
MAX	• maximum	PDM	• pulse-duration modulation	SQ	• square	WV	• working inverse voltage
MT	• megohm	PF	• picofarad	SWR	• standing-wave ratio	WV	• working inverse voltage
MEG	• meg (10 ⁶) (used in parts list)	PH	• phosphor bronze	SYN	• synchronous	WV	• working inverse voltage
MET FLM	• metal film	PHZ	• Philips	TA	• tangent	WV	• working inverse voltage
MET OX	• metal oxide	PHN	• positive-negative-negative	TC	• temperature compensating	WV	• working inverse voltage
MF	• medium frequency; microfarad (used in parts list)			TD	• time delay	WV	• working inverse voltage
MFR	• manufacturer			TERM	• terminal	WV	• working inverse voltage
mg	• milligram					WV	• working inverse voltage
MHz	• megahertz					WV	• working inverse voltage
mH	• millihenry					WV	• working inverse voltage
mho	• mho					WV	• working inverse voltage
MIN	• minimum					WV	• working inverse voltage

NOTE

All abbreviations in the parts list will be in upper case.

MULTIPLIERS

Abbreviation	Prefix	Multiple
T	tera	10 ¹²
G	giga	10 ⁹
M	mega	10 ⁶
k	kilo	10 ³
d	deka	10 ¹
c	centi	10 ⁻²
m	milli	10 ⁻³
µ	micro	10 ⁻⁶
n	nano	10 ⁻⁹
p	pico	10 ⁻¹²
f	femto	10 ⁻¹⁵
a	atto	10 ⁻¹⁸

Model 6501A Replaceable Parts

Table 5-1. Replaceable Parts

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
A1	06501-00701	1	CONNECTOR BOARD ASSEMBLY	28480	06501-00701
A1C1	0180-1746	4	CAPACITOR-FX01 150UF+-10% 25VDC TA-SOLID	28480	1801180703009
A1C2	0180-1746	4	CAPACITOR-FX01 150UF+-10% 25VDC TA-SOLID	28480	1801180703009
A1C3	0180-0230	4	CAPACITOR-FX01 1UF+-20% 50VDC TA-SOLID	28480	1307103000301
A1C4	0180-0230	4	CAPACITOR-FX01 1UF+-20% 50VDC TA-SOLID	28480	1307103000301
A1C5	0180-0067	2	CAPACITOR-FX01 47UF+-10% 25VDC TA	04300	1600763003652
A1C6	0180-1746	4	CAPACITOR-FX01 150UF+-10% 25VDC TA-SOLID	28480	1801180703009
A1C7	0180-1746	4	CAPACITOR-FX01 150UF+-10% 25VDC TA-SOLID	28480	1801180703009
A1C8	0180-0137	2	CAPACITOR-FX01 33UF+-20% 25VDC CEN	28480	0180-0137
A1C9	0180-0137	2	CAPACITOR-FX01 33UF+-20% 25VDC CEN	28480	0180-0137
A1C10	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C11	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C12	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C13	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C14	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C15	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C16	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C17	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C18	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C19	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C20	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C21	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C22	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C23	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C24	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C25	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C26	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C27	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C28	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C29	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C30	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C31	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C32	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C33	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C34	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C35	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C36	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C37	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C38	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C39	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C40	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C41	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C42	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C43	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C44	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C45	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C46	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C47	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040
A1C48	1901-0040	8	DIODE-SWITCHING 2HS 30V 50MA	28480	1901-0040

See Introduction to this section for ordering information

Model 5501A Replaceable Parts

Table 5-1. Replaceable Parts (cont'd)

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
AS	00601-00704	1	LOCK REFERENCE BOARD ASSEMBLY	26480	00601-00704
ABC1	0180-0118	1	CAPACITOR-FXND 0.01UF +-10% 35VDC TA	26289	1800105XV03BA2
ABC2	0180-0291	7	CAPACITOR-FXND 1UF +-10% 35VDC TA-SOLID	26289	1800105XV03BA2
ABC3	0180-0090	1	CAPACITOR-FXND 1000PF +-5% 50V 100WVDC	26480	0180-0090
ABC4	0180-0291	1	CAPACITOR-FXND 1UF +-10% 35VDC TA-SOLID	26289	1800105XV03BA2
ABC5	0180-0298	1	CAPACITOR-FXND 100PF +-5% 100WVDC NICA	26480	0180-0298
ABC6	0180-0291	1	CAPACITOR-FXND 1UF +-10% 35VDC TA-SOLID	26289	1800105XV03BA2
ABC7	0180-0298	1	CAPACITOR-FXND 0.01UF +-10% 35VDC CER	26480	0180-0298
ABC8	0180-0298	2	CAPACITOR-FXND 0.033UF +-10% 200WVDC POLYF	26289	262P33342
ABC9	0180-0298	1	CAPACITOR-FXND 0.01UF +-10% 35VDC CER	26480	0180-0298
ABC10	0180-0298	1	CAPACITOR-FXND 0.033UF +-10% 200WVDC POLYF	26289	262P33342
ABC11	0180-2204	2	CAPACITOR-FXND 100PF +-5% 300WVDC NICA	26480	0180-2204
ABC12	0180-2095	1	CAPACITOR-FXND 0.01UF +-10% 35VDC CER	26480	0180-2095
ABC13	0180-0291	1	CAPACITOR-FXND 1UF +-10% 35VDC TA-SOLID	26289	1800105XV03BA2
ABC14	0180-2095	1	CAPACITOR-FXND 0.01UF +-10% 35VDC CER	26480	0180-2095
ABC15	0180-2095	1	CAPACITOR-FXND 0.01UF +-10% 35VDC CER	26480	0180-2095
ABC16	0180-2095	1	CAPACITOR-FXND 0.01UF +-10% 35VDC CER	26480	0180-2095
ABC17	0180-0291	1	CAPACITOR-FXND 1UF +-10% 35VDC TA-SOLID	26289	1800105XV03BA2
ABC18	0180-2095	1	CAPACITOR-FXND 0.01UF +-10% 35VDC CER	26480	0180-2095
ABC19	0180-2095	1	CAPACITOR-FXND 0.01UF +-10% 35VDC CER	26480	0180-2095
ABC20	0180-2095	1	CAPACITOR-FXND 0.01UF +-10% 35VDC CER	26480	0180-2095
ABC21	0180-2204	1	CAPACITOR-FXND 100PF +-5% 300WVDC NICA	26480	0180-2204
ABC22	0180-0181	1	CAPACITOR-FXND 0.01UF +-10% 35VDC POLYF	26289	262P10392
ABC23	0180-0188	1	CAPACITOR-FXND 0.01UF +-10% 35VDC TA	26289	1800105XV03BA2
ABC24	0180-0178	1	CAPACITOR-FXND 2.2UF +-20% 50VDC CER	26480	0180-0178
ABC25	00600-00003	1	PHOTO-DIODE, SILICON UNMATCHED PAIR FOR CR1 AND CR2	26480	00600-00003
ABC26	1901-0040	1	DIODE-ZNR 16.2V 5% DO-7 PD=0.4W TC=+0.044	04713	1901-0040
ABC27	1901-0040	1	DIODE-SWITCHING 2HS 30V 50MA	26480	1901-0040
ABC28	1902-3149	1	DIODE-ZNR 9.0V 5% DO-7 PD=0.4W TC=+0.0378	04713	1902-3149
ABC29	1901-0040	1	DIODE-SWITCHING 2HS 30V 50MA	26480	1901-0040
ABC30	1901-0040	1	DIODE-SWITCHING 2HS 30V 50MA	26480	1901-0040
ABC31	1902-3782	1	DIODE-ZNR 22.5V 5%	26480	1902-3782
ABC32	1902-0049	1	DIODE-ZNR 6.1V 5% DO-7 PD=0.4W TC=+0.022	04713	1902-0049
ABC33	1910-0034	2	DIODE-SWITCHING 2HS 30V 50MA	26480	1910-0034
ABC34	1910-0034	1	DIODE-SWITCHING 2HS 30V 50MA	26480	1910-0034
ABC35	1902-3149	1	DIODE-ZNR 12.1V 5% DO-7 PD=0.4W TC=+0.044	04713	1902-3149
ABC36	1854-0071	1	TRANSISTOR NPN 51 PD=300MW FT=200NHZ	26480	1854-0071
ABC37	1854-0215	4	TRANSISTOR NPN 51 PD=310MW FT=300NHZ	04713	1854-0215
ABC38	1854-0215	1	TRANSISTOR NPN 51 PD=310MW FT=300NHZ	04713	1854-0215
ABC39	1854-0215	1	TRANSISTOR NPN 51 PD=310MW FT=300NHZ	04713	1854-0215
ABC40	1854-0071	1	TRANSISTOR NPN 51 PD=300MW FT=200NHZ	26480	1854-0071
ABC41	1854-0071	1	TRANSISTOR NPN 51 PD=300MW FT=200NHZ	26480	1854-0071
ABC42	1854-0071	1	TRANSISTOR NPN 51 PD=300MW FT=200NHZ	26480	1854-0071
ABC43	1854-0071	1	TRANSISTOR NPN 51 PD=300MW FT=200NHZ	26480	1854-0071
ABC44	1854-0071	1	TRANSISTOR NPN 51 PD=300MW FT=200NHZ	26480	1854-0071
ABC45	1854-0071	1	TRANSISTOR NPN 51 PD=300MW FT=200NHZ	26480	1854-0071
ABC46	1854-0071	1	TRANSISTOR NPN 51 PD=300MW FT=200NHZ	26480	1854-0071
ABC47	1854-0071	1	TRANSISTOR NPN 51 PD=300MW FT=200NHZ	26480	1854-0071
ABC48	1854-0071	1	TRANSISTOR NPN 51 PD=300MW FT=200NHZ	26480	1854-0071
ABC49	1854-0071	1	TRANSISTOR NPN 51 PD=300MW FT=200NHZ	26480	1854-0071
ABC50	1854-0071	1	TRANSISTOR NPN 51 PD=300MW FT=200NHZ	26480	1854-0071
ABC51	0883-1283	1	RESISTOR 1.2M 5% .25W FC TC=+400/+800	01121	CR1283
ABC52	0883-1015	2	RESISTOR 100 5% .25W FC TC=+400/+800	01121	CR1015
ABC53	0883-3945	1	RESISTOR 390K 5% .25W FC TC=+800/+900	01121	CR3945
ABC54	2100-0444	1	RESISTOR-VAR TRIM 20MM 20K C TYP ADJ	73138	72PR2M
ABC55	0883-5835	1	RESISTOR 58K 5% .25W FC TC=+400/+800	01121	CR5835
ABC56	0883-2425	2	RESISTOR 2.4K 5% .25W FC TC=+400/+700	01121	CR2425
ABC57	0883-4735	1	RESISTOR 47K 5% .25W FC TC=+400/+800	01121	CR4735
ABC58	0883-2035	2	RESISTOR 20K 5% .25W FC TC=+400/+800	01121	CR2035
ABC59	0883-2035	1	RESISTOR 20K 5% .25W FC TC=+400/+800	01121	CR2035
ABC60	0883-3115	1	RESISTOR 3.1K 5% .25W FC TC=+400/+700	01121	CR3115
ABC61	0883-1645	1	RESISTOR 160K 5% .25W FC TC=+800/+900	01121	CR1645
ABC62	0883-3435	2	RESISTOR 34K 5% .25W FC TC=+400/+800	01121	CR3435
ABC63	0883-4715	1	RESISTOR 470 5% .25W FC TC=+400/+800	01121	CR4715
ABC64	7883-1035	1	RESISTOR 10K 5% .25W FC TC=+400/+700	01121	CR1035
ABC65	0883-3025	3	RESISTOR 3K 5% .25W FC TC=+400/+700	01121	CR3025
ABC66	0683-1635	1	RESISTOR 16K 5% .25W	01607	CR1635
ABC67	0883-4235	4	RESISTOR 42K 5% .25W FC TC=+400/+800	01121	CR4235
ABC68	0883-1945	2	RESISTOR 190K 5% .25W FC TC=+800/+900	01121	CR1945
ABC69	0883-1035	1	RESISTOR 10K 5% .25W FC TC=+400/+700	01121	CR1035
ABC70	0883-1845	1	RESISTOR 180K 5% .25W FC TC=+800/+900	01121	CR1845
ABC71	0883-1015	2	RESISTOR 100 5% .25W FC TC=+400/+800	01121	CR1015
ABC72	0883-4935	1	RESISTOR 49K 5% .25W FC TC=+400/+800	01121	CR4935
ABC73	0883-2025	3	RESISTOR 2K 5% .25W FC TC=+400/+700	01121	CR2025
ABC74	0883-1835	1	RESISTOR 18K 5% .25W FC TC=+400/+800	01121	CR1835
ABC75	0883-9125	1	RESISTOR 9.1K 5% .25W FC TC=+400/+700	01121	CR9125
ABC76	0883-2425	1	RESISTOR 2.4K 5% .25W FC TC=+400/+700	01121	CR2425
ABC77	0883-4315	1	RESISTOR 430 5% .25W FC TC=+400/+800	01121	CR4315
ABC78	0883-1025	4	RESISTOR 1K 5% .25W FC TC=+400/+800	01121	CR1025
ABC79	0883-1845	1	RESISTOR 180K 5% .25W FC TC=+800/+900	01121	CR1845
ABC80	0883-3435	1	RESISTOR 34K 5% .25W FC TC=+400/+800	01121	CR3435

See introduction to this section for ordering information

Table 5-1. Replaceable Parts (cont'd)

Referance Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
ABR31	0683-3328	1	RESISTOR 3.3K 5% .25W PC TC=+400/+700	01121	CR1325
ABR32	0683-3328	1	RESISTOR 3.3K 5% .25W PC TC=+400/+700	01121	CR1325
ABR33	0683-3328	1	RESISTOR 3.3K 5% .25W PC TC=+400/+700	01121	CR1325
ABR34	0683-3328	1	RESISTOR 3.3K 5% .25W PC TC=+400/+700	01121	CR1325
ABR35	0683-1036	1	RESISTOR 10K 5% .25W PC TC=+400/+700	01121	CR1036
ABR36	0683-4728	1	RESISTOR 4.7K 5% .25W PC TC=+400/+700	01121	CR4728
ABR37	0683-3328	1	RESISTOR 3.3K 5% .25W PC TC=+400/+700	01121	CR1325
ABR38	0683-3328	1	RESISTOR 3.3K 5% .25W PC TC=+400/+700	01121	CR1325
ABR39	0683-1028	1	RESISTOR 1K 5% .25W PC TC=+400/+700	01121	CR1028
ABR40	0683-3328	1	RESISTOR 3.3K 5% .25W PC TC=+400/+700	01121	CR1325
ABR41	0683-1538	1	RESISTOR 15K 5% .25W PC TC=+400/+700	01121	CR1538
ABR42	2100-1944	1	RESISTOR-VAR TRIMMER 10K C TOP ADJ	2100-1944	170-107
ABR43	0683-1028	1	RESISTOR 1K 5% .25W PC TC=+400/+700	01121	CR1028
ABR44	0683-1028	1	RESISTOR 1K 5% .25W PC TC=+400/+700	01121	CR1028
ABR45	0683-3328	1	RESISTOR 3.3K 5% .25W PC TC=+400/+700	01121	CR1325
ABR46	0683-3028	1	RESISTOR 3K 5% .25W PC TC=+400/+700	01121	CR3028
ABR47	1004-0412	1	RESISTOR 1K 5% .25W PC TC=+400/+700	1004-0412	0686-0412
ABR48	0683-3028	1	RESISTOR 3K 5% .25W PC TC=+400/+700	01121	CR3028
ABR49	0683-1818	1	RESISTOR 18K 5% .25W PC TC=+400/+700	01121	CR1818
ABU1	1824-0025	1	IC LM308AH	27014	LM308AH
ABU2	1824-0479	1	IC LM308H	27014	LM308H
ABU3	1824-0720	1	IC ON78 30H	27014	ON7830H
ABU4	1824-0045	6	IC LM311H	27014	LM311H
AD	08501-60203	1	PAY POWER SUPPLY ASSEMBLY (NON-REPAIRABLE)	28480	08501-60203
AI	18401-00708	1	Central Base Assembly	28480	08501-60203
AIC1	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC2	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC3	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC4	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC5	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC6	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC7	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC8	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC9	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC10	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC11	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC12	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC13	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC14	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC15	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC16	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC17	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC18	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC19	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC20	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC21	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC22	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC23	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC24	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC25	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC26	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC27	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC28	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC29	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC30	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC31	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC32	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC33	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC34	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC35	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC36	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC37	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC38	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC39	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC40	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC41	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC42	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC43	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC44	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC45	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC46	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC47	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC48	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC49	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC50	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC51	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC52	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC53	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC54	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC55	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC56	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC57	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC58	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC59	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC60	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC61	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC62	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC63	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC64	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC65	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC66	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC67	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC68	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC69	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC70	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC71	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC72	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC73	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC74	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC75	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC76	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC77	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC78	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC79	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC80	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC81	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC82	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC83	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC84	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC85	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC86	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC87	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC88	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC89	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC90	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC91	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC92	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC93	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC94	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC95	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC96	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC97	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC98	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC99	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC100	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC101	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC102	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC103	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC104	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC105	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC106	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC107	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC108	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC109	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC110	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC111	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC112	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC113	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC114	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC115	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC116	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC117	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC118	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	1600724DC3AN7
AIC119	0180-0180	1	Capacitor Fed. 22UF, 10V, 50VDC	0180-0180	16007

See Introduction to this section for ordering information

Model 5501A
Replaceable Parts

Table 5-1. Replaceable Parts (cont'd)

Reference Designation	HP Part Number	Qty	Description	Mfr Code	Mfr Part Number
			MISC. & CHASSIS MOUNTED PARTS		
Q1	1894-0063	1	TRANSISTOR NPN 2N3055 51 10-3 PD-115W	28480	1894-0063
W1	05501-40001	1	CABLE ASSY, MAIN	28480	05501-40001
W2	05501-40004	1	CABLE ASSY, CATHODE	28480	05501-40004
X01	1200-0041	1	SOCKET, ELCC, NETA 2-CONT 10-3 PKG 1LDM	00014	PYS-1
			MISCELLANEOUS PARTS		
	0510-0087 1000-0353	1	RETAINER, PUSH UN, .25 DIA, CAD PLY STL WINDOW PLATE	97446 28480	0100-23-57-ED 1000-0353
	1281-3467	1	CONNECTOR, 4-CONT; CIRCULAR (MATES WITH J1)	05932	8704ECS-4P
	1281-3460	1	CONNECTOR, 4-CONT; MALE; CIRCULAR (MATES WITH J2)	00677	8704ECS-4P
	1281-3748	1	STRAIN RELIEF	28480	1281-3748
	7120-2444 7120-8180	1	LABEL, IDENT "5501A LASER TRANSDUCER" LABEL, "CAUTION"	28480 28480	7120-2444 7120-8180
	7120-3731 7122-0097 9320-1744 05501-00001 05501-00003	1 1 1 1 1	LABEL, HV WARNING SER PLY "SERIAL NO; INWLETT PACKARD- LABEL, MAGNETIC SUPPORT, LATCH COVER, LEFT	28480 28480 28480 28480 28480	7120-3731 7122-0097 9320-1744 05501-00001 05501-00003
	05501-00005 05501-20001 05501-20002 05501-20003 05501-20006	1 1 1 1 1	SHIELD PANEL, FRONT PANEL, REAR FOOT, MOUNTING BASE, LASER	28480 28480 28480 28480 28480	05501-00005 05501-20001 05501-20002 05501-20003 05501-20006
	05501-20014 05501-20016 05501-40001 05501-40003 05501-40004	1 1 1 1 1	INSULATOR, RIGID INSULATOR, LONG NCADER, PHOTOODDER MOUNT, SHUTTER SHUTTER	28480 28480 28480 28480 28480	05501-20014 05501-20016 05501-40001 05501-40003 05501-40004
	05501-40007 06600-80002	1	COVER ASSEMBLY, RIGHT LABEL, "HP AND DATE"	28480 28480	05501-40007 06600-80002
Note 1 Note 1	10778A.D.C 10778A.D.C		6, 10, 20 Metres Power Cable 6, 10, 20 Metres Reference Cable	28480 28480	10778A.D.C 10778A.D.C

Note 1: These cables are not supplied, order separately.

See Introduction to this section for ordering information

Table 5-2. Manufacturers Code List

Mfr. Number	Manufacturer Name	City	ZIP Code
00014	Any Supplier of U.S.A.		
01121	Allen Bradley Co.	Milwaukee, WI	53212
01295	Texas Instruments, Inc., Semiconductor Component Div.	Dallas, TX	75231
02735	RCA Corp., Solid State Division	Somerville, NJ	08876
04713	Motorola Semiconductor Products	Phoenix, AZ	85008
09353	C and K Components, Inc.	Watertown, MA	02172
09922	Brundy Corp.	Norwalk, CT	06852
11502	TRW, Inc., Boone Division	Boone, NC	28607
19701	Mejco/Electra Corp.	Mineral Wells, TX	76067
24546	Corning Glass Works (Bradford)	Bradford, PA	16701
32014	National Semiconductor Corp.	Santa Clara, CA	95051
20480	Hewlett-Packard Company, Corporate Headquarters	Palo Alto, CA	94304
34335	Advanced Micro Devices, Inc.	Sunnyvale, CA	94086
56289	Sprague Electric Co.	North Adams, MA	01247
71400	Bussman Mfg., Division of McGraw-Edison Co.	St. Louis, MO	63017
73138	Beckman Instruments Inc., Hellpot Division	Fullerton, CA	92634
77820	Bendix Corp., Electronic Component Division	Sidney, NY	13038
84048	TRW Inc., St. Petersburg Division	St. Petersburg, FL	33702
97464	Industrial Retaining Ring Co.	Irvington, NJ	07111

BACK DATING MANUAL CHANGES

SECTION VI

MANUAL CHANGES AND OPTIONS

6-1. INTRODUCTION

6-2. This section of the manual contains information necessary to update the manual to cover newer instruments and to backdate the manual to cover older instruments. Additionally, options available for the laser head are described in this section.

6-3. MANUAL CHANGES

6-4. This manual applies directly to units having serial number prefix 1736A, except for 1736A 00592 (see Table 6-1). For units with different serial number prefixes, refer to the following paragraphs.

6-5. Newer Instruments

6-6. Newer instruments may have higher serial number prefixes than those listed on the title page of this manual. The manuals for these units will include "Manual Changes" sheets that describe all required manual changes. If the updating information is missing, contact the local HP Sales and Service Office for information.

6-7. Older Instruments

6-8. Table 6-1 lists the serial numbers and serial number prefixes of units that differ electrically from the units documented in this manual. Find the prefix or range of serial numbers that corresponds to your unit, and make the manual changes specified in Table 6-1.

Table 6-1. Backdating

Serial Number or Prefix	Make These Manual Changes
194B	1
1736	1, 2
1736A00592	1, 2, 3
1732A	1, 2, 3, 4
1724A	1, 2, 3, 4, 5
1712A00395, 425, 427-430, 432, 433, 436, 439, 440	1, 2, 3, 4, 5
1712A	1, 2, 3, 4, 5, 6
1628A	1 thru 7
1620A	1-8
1616A	1-9
1612A	1-10
1604A	1-11
1544A	1-12
1436A (Note)	1-13
1424A and 1428A with serial numbers 00121 and above	1-14
1424A and 1428A with serial numbers below 00121	1 through 14. Also, some units require 15 through 17. Determine which changes are applicable by physical inspection of unit.
1404A	1 through 17

Model 5501A
Manual Changes and Options

NOTE

Unit serial numbers 1436A00107, 1436A00109, 1436A00200, 1436A00208, 1436A00215, and 1436A00216 include change 11.

Change 1:

Page 1-1, Paragraph 1-12:

Change paragraph to read: "The Laser Head is supplied with a power cable 05501-60009 and a reference cable 05501-60008."

Page 5-6, Table 5-1, Replaceable Parts:

Delete 10770ABC listing. Delete 10779ABC listing. Delete Note 1. Add 05501-60009 Power Cable 20480, 05501-60009. Add 05501-60008 Reference Cable 20480 05501-60008.

Change 2:

Page 1-1, Paragraph 1-12:

Change paragraph to read: "Three plugs that mate with the laser head rear-panel jacks are included with the laser head. System interconnection of the laser head is accomplished by fabricating suitable cables that terminate with these plugs. Refer to Section II of this manual for cable fabricating instructions."

Page 5-6, Table 5-1, Replaceable Parts:

Delete 05501-60009 and listing. Delete 05501-60008 and listing.

Change 3:

Page 5-3, Table 5-1, and page 7-13, Figure 7-13, change A2 from 05501-60200 to 05501-60206, (Parts list and Schematic Diagram)

Change 4:

Page 5-3, delete A1C8 and A1C9.

Page 7-11, replace A1C8 and A1C9 with straight through connections.

Change 5:

Page 5-7, change A7R11 to 0757-0209 RESISTOR 13.3K 1% .125W, 20480, 0757-0209.

Change A7R20 to 0603-1335 RESISTOR 13K 5% .25W, 20480, 0603-1335.

Page 7-19, change A7R11 to 13.3K. Change A7R20 to 13K.

Change 6:

Page 5-3, change A1R1 and A1R2 to 0603-1535 RESISTOR 15K 5% .25W, 20480, 0603-1535.

Change A1R13 to 0757-0952 RESISTOR 15K 2% .125W, 20480, 0757-0952.

Page 5-4, change A5C24 to 0160-0127 CAPACITOR-FXD; 1UF $\pm 20\%$ 25 WVDC CER, 20480, 0160-0127.

Change A5CR5 to 1502-0025 DIODE-ZNR 10V 5%, 20480, 1502-0025.

Change A5CR8 to 1902-3224 DIODE-ZNR 17.0V 5%, 20480, 1502-3224.

Page 5-7, change A7R8 to 0603-2715 RESISTOR 1.5K 5% .25W, 20480, 0603-2715.

Change A7R10 to 0603-1525 RESISTOR 1.5K 5% .25W, 20480, 0603-1525.

Change A7R11 to 0603-1335 RESISTOR 13K 5% .25W, 20480, 0603-1335.

Page 7-9, change A5CR8 to 17V. Change A5C24 to 1UF.

Page 7-19, change A7R11 to 13K. Change R10 to 1.5K. Change R8 to 270.

Change 7:

Page 5-3, change A1C5 to 0180-0116 CAPACITOR-FXD 6.8UF $\pm 10\%$ 35VDC TA, 20480, 0180-0115.

Page 5-4, change A5C24 to 0160-0127 CAPACITOR-FXD 1UF $\pm 20\%$ 25 WVDC CER, 20480, 0160-0127.

Change A5CR5 to 1902-3149 DIODE-ZNR 9.09V 5%, 20480, 1902-3149.

Page 5-4, change A5R16 to 0603-1535 RESISTOR 15K 5% .25W, 20480, 0603-1535.

Page 5-7, change A7C1 and A7C2 to 0180-0374 CAPACITOR-FXD 10UF 20 VDC, 20480, 0180-0374.

Page 7-11, change A1C5 to 6.8UF.

Page 7-15, change A5C24 to 1UF. Change A5CR5 to 9V. Change A3R16 to 3600.

Page 7-19, change A7C1 and A7C2 to 10UF 20V.

Change 8:

Page 5-4, Table 5-1:

Change A5CR1 from 05500-00003 to 1990-0338, 2, PHOTO-DIODE: SILICON, 20480, 1990-0338, Obsolete, pages 5-7 and 5-8 (Replaceable Parts for A7 Series 1620) but keep in your manual.

Page 7-19, Figure 7-12:

Mark this page as obsolete but keep it in the manual. After page 7-19 insert Figure 7-12A. This page can be found at the end of this manual section. (Be sure to change page number to read 7-19a.)

Change 9:

Page 7-13, Figure 7-7:

Make a note on this drawing to the effect the Resistors R7 and R8 are 47K in series 1616A and below.

Change 10:

Page 5-3, Table 5-1:

Change A152 HP Part Number and Mfr. Part Number from 3101-2116 to 3101-1676.

Page 7-11, Figure 7-6:

Change A1 Connector Board Series from 1616A to 1428A.

Change 11:

Page 7-13, Figure 7-7:

Delete the following note:

NOTE

A2 HV Power Supply board was series 1604A, which was replaced by series 1612A.

Change 12:

Page 5-3, Table 5-1:

Change A1D51, D52, D53, D54, D55, D56, D57, and D58 Part Numbers from 1990-0405 to 1990-0416; (Change both the HP Part Number and Mfr. Part Number columns.)

Page 5-6, Table 5-1:

Delete 7120-5100, 1, Label, "CAUTION" and 05500-00002, 1, Label, "HP and DATE".

Add HP Part Number 7210-2562, 1, Label "CAUTION: LASER MEDIUM; MAX", 20480, 7120-2562.

Change 13:

Page 5-3, Table 5-1:

Change A2 HP Part Number and Mfr. Part Number from 05501-60206 to 05501-60202.

Page 7-7, Table 7-1:

Change Part Number of Ref. Desig. A2 to 05501-60202.

Page 7-13, Figure 7-7:

Add Figure 7-7A which is located at the end of this manual section. (Be sure to change page number of Figure 7-7A to read 7-13a.)

Keep page 7-13, Figure 7-7 and mark it obsolete.


Page 7-19a, Figure 7-12A:

Add R24 resistor (1000 ohms) from pin "H" (LASER CATHODE) to ground.

Page 5-5, Table 5-1:

Change A7R1 to 0683-1035 (10K ohm).

LASER
CATHODE
FROM
AIJ4-3



Change 14:

On the schematic diagram of Figure 7-9 and in the replaceable parts list, Table 5-1, change resistor A5R1 from 1.2M (part number 0603-1255) to 2M (part number 0603-2055) and change resistor A5R3 from 390K (part number 0603-3945) to 1M (part number 0603-1055).

Model 5501A
Manual Changes and Options

Change 15:

On the functional diagram of Figure 7-4, the schematic diagram of Figure 7-6, and in the replaceable parts list of Table 5-1, delete C1 (the 100 μ F capacitor that is connected between the base of Q1 and the chassis common return connection).

Change 16:

On the schematic diagram of Figure 7-9 and in the replaceable parts list of Table 5-1, change resistor A8R47 from 1.3 ohms (part number 0690-0070) to 13 ohms (part number 0603-1305).

Change 17:

On the schematic diagram of Figure 7-6 and in the replaceable parts list of Table 5-1, delete A1C7 (the 0.001 μ F capacitor connected to the base of A1Q3).


6-9. OPTIONS

6-10. Table 6-2 lists power supply options that are available for use with the laser head and associated system components. These options do not include the laser head and consist of power supplies only.

Table 6-2. Power Supply Options

DUAL OUTPUT SUPPLIES							
Option No.	Consists of:	Input Line Voltage	Maximum Input Power	Output Voltage	Output Current	Current Derating	Size
007	62215A-J27,011	115V	90W	$\pm 15V$	1.25A each side	•	1/8 rack
011	62215A-J27,011,102	230V	90W	$\pm 15V$	1.25A each side	•	1/8 rack
019	62215E-J27,011	115V	215W	$\pm 15V$	3.0A	•	1/4 rack
020	62215E-J27,011,102	230V	215W	$\pm 15V$	3.0A	•	1/4 rack
*Output current derated 20% with 50 Hz line input. Temperature-dependent output current derating linear from 0% at 40° to 50% at 71°C.							
SINGLE OUTPUT SUPPLIES							
Option No.	Consists of:	Input Line Voltage	Maximum Input Power	Output Voltage	Output Current		Size
005	62005A-011	115V	37W	5V	2.0A		1/8 rack
006	62005C-011	115V	80W	5V	4.0A		1/4 rack
007	62005E-011	115V	153W	5V	8.0A		1/4 rack
008	62005G-011	115V	301W	5V	16.0A		1/2 rack
015	62005A-011,102	230V	37W	5V	2.0A		1/8 rack
016	62005C-011,102	230V	80W	5V	4.0A		1/4 rack
017	62005E-011,102	230V	153W	5V	8.0A		1/4 rack
018	62005G-011,102	230V	301W	5V	16.0A		1/2 rack

Figure 7-7A. A2 HV Power Supply Assembly Schematic Diagram



Model 5501A
Circuit Diagram




Figure 7-11A. A7 Control Board Component Locator




Figure 7-12A. A7 Control Board Schematic Diagram

NOTES

1. REFERENCE DESIGNATIONS WITHIN THIS ASSEMBLY ARE ABBREVIATED, ADD ASSEMBLY NUMBER TO ABBREVIATION FOR COMPLETE DESCRIPTION.

2. UNLESS OTHERWISE INDICATED: RESISTANCE IN OHMS; CAPACITANCE IN PICOFARADS.