

11852B Minimum Loss Pad

User's and Service Guide



Part Number 11852-90009

Printed in USA

August 2005

Supersedes June 2001

Notice.

The information contained in this document is subject to change without notice.

Agilent Technologies makes no warranty of any kind with regard to this material, including but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Agilent Technologies shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

Certification

Agilent Technologies certifies that this product met its published specifications at the time of shipment from the factory. Agilent Technologies further certifies that its calibration measurements are traceable to the United States National Institute of Standards and Technology, to the extent allowed by the Institute's calibration facility, and to the calibration facilities of other International Standards Organization members.

Warranty

This Agilent Technologies instrument product is warranted against defects in material and workmanship for a period of one year from date of shipment. During the warranty period, Agilent Technologies will, at its option, either repair or replace products which prove to be defective.

For warranty service or repair, this product must be returned to a service facility designated by Agilent Technologies. Buyer shall prepay shipping charges to Agilent Technologies and Agilent Technologies shall pay shipping charges to return the product to Buyer. However, Buyer shall pay all shipping charges, duties, and taxes for products returned to Agilent Technologies from another country.

Agilent Technologies warrants that its software and firmware designated by Agilent Technologies for use with an instrument will execute its programming instructions when properly installed on that instrument. Agilent Technologies does not warrant that the operation of the instrument, or software, or firmware will be uninterrupted or error-free.

LIMITATION OF WARRANTY

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by Buyer, Buyer-supplied software or interfacing, unauthorized modification or misuse, operation outside of the environmental specifications for the product, or improper site preparation or maintenance.

NO OTHER WARRANTY IS EXPRESSED OR IMPLIED. AGILENT TECHNOLOGIES SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

EXCLUSIVE REMEDIES

THE REMEDIES PROVIDED HEREIN ARE BUYER'S SOLE AND EXCLUSIVE REMEDIES. AGILENT TECHNOLOGIES SHALL NOT BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER BASED ON CONTRACT, TORT, OR ANY OTHER LEGAL THEORY.

Assistance

Product maintenance agreements and other customer assistance agreements are available for Agilent Technologies products. For any assistance, contact your nearest Agilent Technologies Sales and Service Office.

By internet, phone, or fax, get assistance with all your test & measurement needs.

Table 0-1. Agilent Technologies Sales and Service Offices

Online Assistance: www.agilent.com/find/assist


United States (tel) 1 800 452 4844	Japan (tel) (81) 426 56 7832 (fax) (81) 426 56 7840	New Zealand (tel) 0 800 738 378 (fax) 64 4 495 8950
Canada (tel) 1 877 894 4414 (fax) (905) 206 4120	Latin America (tel) (305) 269 7500 (fax) (305) 269 7599	Asia Pacific (tel) (852) 3197 7777 (fax) (852) 2506 9284
Europe (tel) (31 20) 547 2323 (fax) (31 20) 547 2390	Australia (tel) 1 800 629 485 (fax) (61 3) 9210 5947	

11852B Minimum Loss Pad

General Information

To obtain optimum performance from this minimum loss pad, observe these simple precautions.

- Make connections carefully to avoid misalignment and connector damage or inaccurate measurements.
- Keep the connectors free of dirt and metallic particles.
- For information on connector cleaning and care, refer to Agilent Technologies' *Microwave Connector Care Manual*.



Description

The 11852B minimum loss pad is a 50Ω to 75Ω or 75Ω to 50Ω impedance converter with type-N connectors. The standard 11852B has a female 50Ω and a male 75Ω connector. The 11852B Option 004 has a male 50Ω and a female 75Ω connector. The preceding figure is a representation of a standard 11852B.

Caution Mating a 50Ω male connector with a 75Ω female connector will destroy the 75Ω connector.

Operating Characteristics

Frequency range	dc to 3.0 GHz
Nominal insertion loss	5.7 dB
Return loss 75Ω side (50Ω side terminated)	≥ 32 dB, dc to 2 GHz
.....	≥ 27 dB, 2 GHz to 3 GHz
Return loss 50Ω side (75Ω side terminated)	≥ 32 dB, dc to 2 GHz
.....	≥ 27 dB, 2 GHz to 3 GHz
Maximum input power	250 mW (+24 dBm)

Physical Characteristics

Standard connectors	50Ω type-N (f), 75Ω type-N (m)
Option 004 connectors	75Ω type-N (f), 50Ω type-N (m)
Net weight	0.11 kg (4 oz)
Shipping weight	0.26 kg (9 oz)
Diameter	14 mm (0.6 in)
Length	70 mm (2.8 in)
Female center conductor protrusion	0.204 to 0.207 inch
Male center conductor recession	0.208 to 0.211 inch

WEEE Compliance



This product complies with the WEEE Directive (2002/96/EC) marking requirements. The affixed label indicates that you must not discard this electrical/electronic product in domestic household waste. Product Category: With reference to the equipment types in the WEEE Directive Annex I, this product is classed as a "Monitoring and Control Instrumentation" product. Do not dispose in domestic household waste. To return unwanted products, contact your local Agilent office, or see www.agilent.com for more information.

Customer Order Number

For Agilent Internal Reference Only
Manufacturing Part Number



11852-90009

Printed in USA

August 2005